


Service Instructions

Date: 31 October 2005

Re.: Changing the time on GSE 60-series indicators



12.34 kg
Net

11


Key in 11
<Select> to
display date and
time



311005 09:30
:05am

Press <Enter>
to edit the date

If there is no response to
pressing <Enter>, time/date
access needs to be enabled in
setup (parameter 502)



311005 Date

Press <Enter>
again to edit the
time



093007 Time

08.30

Key in a new
value and press
<Enter>

Note that a decimal point is
required between fields and
entry of seconds is optional




083000 Time

Press <Select>
to return to
date/time
display



311005 08:30
:05am

Press <Select>
again to return
to weigh mode



12.34 kg
Net

Service Instructions

Date: 31 October 2005


Re.: Enabling date/time access on the GSE 60-series indicators



12.34 kg
Net

100

Key in
100<Select> to
go to setup
mode




SETUP Keyin
Code:

23640

Key in the
access code


If there is no <ID> key on the
particular model then omit it
from the access code entry



P100.01 Scale
1


502

Key in 502
<Select> to go
to the date/time
access
parameter



P502.00 TDAcc
Disbl

Press <Enter>
to toggle
between
disabled and
enabled



P502.01 TDAcc
Enbl

Press <Zero>
<Clr> <Enter>
<Enter> to exit
and save
changes

Note: pressing <Zero> initiates
the exit setup routine, follow
the prompts for calibration,
save and exit (Clr=No,
Enter=Yes)



12.34 kg
Net

NOTE: To change the date/time without enabling operator access then go into setup mode as above and edit the time at P500 and / or date at P501.